

Connection Instruction

1, Cut the pipe to wanted length.



2, Round and Bevel the pipe end with a reamer.



3, Choose the right size press fitting for the pipe, the fitting and pipe specifications should be compatible.

4, Straight push the fitting insert into the pipe until it reaches the plastic block (end of fitting inside), the pipe can be seen through the inspection holes.



5, Choose correct size clamping tool according to the pipe size. Position the jaws so that their ends align with the press sleeve's end which is by the plastic ring, close the pressing clamp completely.



6, Open the handles, remove the clamping tool from the fitting and installation is finished.



STRAIGHT UNION



ELBOW



TEE